



Ref No.	Part Number	PARTS NAME	QTY
1	9110-08010-DX	Screw M8x10	4
2	LSA22-00025	Valve Plate	1
3	LSM30-05000	Control Valve	1
4	9301-08000-DX	Flat Washer 08	8
5	9206-08000-DX	Hex Lock Nut MB	8
6	LSP25-00003-DX	Spring	2
7	9404-04036-DX	Cotter Pin 04x36	2
8	LSE20-07001	Handle Ball	1
9	9101-10025-DX	Hex Bolt M10x25	4
10	9402-05030-DX	Pin 05x30	1
11	9101-06060-DX	Hex Bolt M6x60	1
12	9608-51102	Push Bearing	1
13	9206-06000-DX	Nylon Lock Nut M6	1
14	LST37-00012	90° Angle Connector	1
15	LST37-00003	Valve Joiner A	1
16	9905-20000	Combination Washer 020	4
17	LSP25-17000	Combination Joiner	1
18	LST37-00013	Jockey Wheel Handle	1
19	9901-15*2.5	O ring 015x2.5	1
20	LST37-14000	8" Caster	1
21	LST37-00007	Hydraulic Hose (Valve-Cylinder)	1
22	LST37-00002 '	Bolt Connector M20	2
23	LSP30-00004-DX	Cylinder Mounting Pin	1
24	LST37-00007	Cylinder	1
25	9901-17*2.5	O Ring 017x2.5	2
26	LSP25-00005-DX	R Pin 05	2
27	LST37-01000	Beam Weldment	1
28	LST37-03000	Right Log Cradle	1
29	9206 14000-DX	Hex Lock Nut M14	1
30	9101 14080-0X8.8	Hex Bolt M14x80	1
31	LST37-05000	Wedge (Axe Head)	1
32	9117-12055-DX12.9	Screw M12x55	10
33	9301-12000-DX	Flat Washer 012	18
34	9306-12000-DX	Lock Washer 012	10
35	9210-12000-DX	Thick Hex Nut M12	10

Ref No.	Part Number	PARTS NAME	QTY
36	LSA22-03001	Keeoer Plate	2
37	LST37-00001	Wood Trav	1
38	LST37-11000	Wood Trav Frame	1
39	9101-08035-DX	Hex Bolt M8x35	4
40	LST37-02000	Left Log Cradle	1
41	9101-10030-DXB.8	Hex Bolt M10x30	18
42	9301-10000-DX	Flat Washer Ø10	27
43	9206-10000-DX	Hex Lock Nut M10	28
44	LSA22-15000	Rear Support Leg	1
45	9101-10075-DXB.8	Hex Bolt M10x75	5
46	LSP22-16000	Hitch Pin	1
47	LSP25-00012	R Pin	1
48	LSA22-00015-DX	Hinge Pin	1
49	9404-04040-DX	Cotter Pin 04x40	1
50	LSP25-13000	Oil Bolt	1
51	LST37-10000	Oil Tank	1
52	9304-62000-FH	Circlip for Shaft Ø62	1
53	LSA22-18000	Right Protection Fender	1
54	9101-12040-DXB.8	Hex Bolt M12x40	4
55	9206-12000-DX	Hex Lock NutM12	7
56	LSA22-17000	Left Protection Fender	1
57	9404-03030-D X	Cotter Pin 03x30	2
58	9301-20000-DX	Flat Washer 020	2
59	LSP25-00008-DX	Safety Pin	2
60	9399-12000-DX	Thick Flat Washer 012	4
61	LSA22-13000	Safety Chain with Hook	2
62	Z105	50mm Coupler	1
63	9101-12130-DXB.8	Hex Bolt M12x130	2
64	9101-12090-DXB.8	Hex Bolt M12x90	1
65	LST37-06000	Tow Bar	1
66	LSP25-00010-DX	Oil Plug	1
67	LSP30-00007	Oil Filter	1
68	LST37-04000	Engine Mounting Plate	1
69	LSP30-00006	Rubber Washer	1
70	LSP30-15000-DX	Oil Filter Mounting Plate	1

Ref No.	Part Number	PARTS NAME	QTY
71	9101-06020-DXB.8	Hex Bolt M6x20	6
72	9306-06000-DX	Lock Washer 06	6
73	9301-06000-DX	Flat Washer 06	6
74	LSP25-00020-FH	Slotted Nut M20	2
75	LSP25-00009-DX	Axle Cap	2
76	NS10-02002-DX	Jockey Wheel Handle Bushing	1
77	LSP25-14000	Wheel / Tire Assembly	2
78	LST37-08000	Outside Wheel Bushing	1
79	LST37-09000	Jockey Wheel outer Cylinder	1
80	NS10-02001	Jockey Wheel Screw rod	1
81	LST37-00016	Oil Return Pine Connector	1
82	9121-06010-FH	Screw M6x10	1
83	LSP35-0200	Gasoline Engine 13HP	1
84	LSP35-00001	Polyurethane Block	4
85	9302-10000-DX	Bia Flat Washer010	4
86	9101-08025-DX8.8	Hex Bolt M8x25	4
87	9306-08000-DX	Lock Washer 08	8
88	LSP25-10008-FH	Steel Wire Snap Ring for Shaft	1
89	9101-08030-DX8.8	Hex Bolt M8x30	4
90	LST37-00014	Outlet Connector of Pump	1
91	LSP35-02006	Gear Pump 116GPMI	1
92	8801-3X3X25	Flat Key	1
93	LSP35-02003	Gear Pump Connector	1
94	LSP35-02002	Engine Connector	1
95	LSP35-02004-DX	Engine Bushing	1
96	LSP35-02005	Gear Pump Stand	1
97	8801-7X7X40	Flat Key	1
98	9101-05010-DX8.8Q	Hex Bolt M5x10	4
99	LSP25-10006	Connector Cover	1
100	9901-14*2.5	O Rina 14x2.5	2
101	LST37-00006	Hydraulic Hose /Valve-Oil Tank\	1
102	LST37-00008	Hydraulic Hose valve-Pump	1
103	LSP25-00011-DG	Hose Clamp	2
104	LST37-00011	Oil Pipe	1
105	LSA22-00021	Rubber Washer 2	6