

# **RedGum GP200 Silver Edition Log Splitter**

## **Illustrated Parts Listing (IPL)**

# **RedGum** Products


**For more information contact your local RedGum Dealer**

**Visit: [www.RedGumProducts.com.au](http://www.RedGumProducts.com.au)**

**Phone: 1300 039 251**



**Follow us on Facebook: [www.facebook.com/redgumproducts](http://www.facebook.com/redgumproducts)**



## Parts Drawing & Parts List

| Ref# | Drawing No.       | Description                              | Qty |
|------|-------------------|------------------------------------------|-----|
| 1    | LSH2200-01000     | Beam Weldment                            | 1   |
| 2    | LSE20-02000       | Wedge                                    | 1   |
| 3    | LSA22-03001       | Keeper Spacer                            | 2   |
| 4    | 9117-12055-DX10.9 | Screw M12x55                             | 10  |
| 5    | 9301-12000-DX     | Flat Washer Ø12                          | 18  |
| 6    | 9306-12000-DX     | Lock Washer Ø12                          | 10  |
| 7    | 9210-12000-DX     | Hex Thick Nut M12                        | 10  |
| 8    | LSP25-05000       | Hitch Pin                                | 1   |
| 9    | LSH22-06009       | Piston Head Joint                        | 1   |
| 10   | 9201-08000-DX     | Hex Nut M8                               | 1   |
| 11   | 9101-08020-DX8.8Q | Hex Bolt M8x20                           | 3   |
| 12   | LSH22-00003-DX    | Wedge Pin                                | 1   |
| 13   | 9404-04040-DX     | Cotter Pin Ø4x40                         | 2   |
| 14   | N280-00043-FH     | Adjusting Washer C                       | /   |
| 15   | 9301-18000-DX     | Flat Washer Ø18                          | 4   |
| 16   | 9306-18000-DX     | Lock Washer Ø18                          | 4   |
| 17   | 9201-18000-DX     | Hex Nut M18                              | 4   |
| 18   | LSH2200-04000     | Cylinder                                 | 1   |
| 19   | LSH2200-00002     | Hydraulic Hose (Valve-Cylinder)          | 1   |
| 20   | 9901-11×2.5       | O Ring Ø11x2.5                           | 4   |
| 21   | LNS22-00003       | Angle Connector                          | 2   |
| 22   | LSH2200-05000     | Control Valve                            | 1   |
| 23   | LSA22-00025       | Plate                                    | 1   |
| 24   | 9110-08010-DX     | Screw M8x10                              | 4   |
| 25   | LSH22-00012-DX    | Oil Return Connector                     | 2   |
| 26   | 9901-14×2.5       | O Ring Ø14x2.5                           | 2   |
| 27   | LSH22-00007       | Hydraulic Hose (Valve-Oil Return Filter) | 1   |
| 28   | LSH2200-00006     | Connector                                | 1   |
| 29   | LSH2200-00003     | Hydraulic Hose (Valve-Pump)              | 1   |
| 30   | LSP25-17002-DX    | Nut                                      | 1   |
| 31   | LSP25-17001-DX    | Valve B Connector                        | 1   |
| 32   | 9901-16*2.5       | O Ring Ø16x2.5                           | 1   |
| 33   | LSA22-00009-DX    | Cylinder Head Connector                  | 1   |
| 34   | LSP30MD-02000     | Manual Canister                          | 1   |
| 35   | 9101-06020-DX8.8  | Hex Bolt M6x20                           | 9   |

## Parts Drawing & Parts List

| Ref# | Drawing No.      | Description            | Qty |
|------|------------------|------------------------|-----|
| 36   | 9301-06000-DX    | Flat Washer Ø6         | 9   |
| 37   | 9206-06000-DX    | Nylon Lock Nut M6      | 3   |
| 38   | LSP25-00012-DX   | R Pin                  | 1   |
| 39   | 9206-10000-DX    | Nylon Lock Nut M10     | 12  |
| 40   | 9301-10000-DX    | Flat Washer Ø10        | 12  |
| 41   | 9101-10050-DX8.8 | Hex Bolt M10x50        | 2   |
| 42   | Z242-01000       | Square Tube (Left)     | 1   |
| 43   | Z242-00002       | Table Stand            | 2   |
| 44   | Z242-02000       | Square Tube (Right)    | 1   |
| 45   | Z242-00001       | Log Table              | 1   |
| 46   | 919901-08035-DX  | Screw M8x35            | 4   |
| 47   | 9301-08000-DX    | Flat Washer Ø8         | 12  |
| 48   | 9206-08000-DX    | Nylon Lock Nut M8      | 12  |
| 49   | LSA22-17000      | Left Fender            | 1   |
| 50   | LSP25-00009      | Axle Cap               | 2   |
| 51   | 9404-04036-DX    | Cotter Pin Ø4x36       | 2   |
| 52   | LSP25-00020-FH   | Hex Slotted Nut M20    | 2   |
| 53   | 9301-20000-DX    | Flat Washer Ø20        | 2   |
| 54   | LSP25-14000      | Wheel                  | 2   |
| 55   | LSP25-00008-DX   | Safety Pin             | 1   |
| 56   | 9404-03030-DX    | Cotter Pin Ø3x30       | 2   |
| 57   | LSP25-00003-DX   | Spring                 | 1   |
| 58   | LST3000-04000    | Tow Bar                | 1   |
| 59   | Z105             | Coupling               | 1   |
| 60   | 9101-12100-DX8.8 | Hex Bolt M12x100       | 4   |
| 61   | 9206-12000-DX    | Nylon Lock Nut M12     | 5   |
| 62   | 9101-12110-DX8.8 | Hex Bolt M12x110       | 1   |
| 63   | LSP25-11000-DX   | Chain with Hook        | 2   |
| 64   | 939902-12000-DX  | Thick Flat Washer Ø12  | 2   |
| 65   | 9304-62000-FH    | Circlips for Shaft Ø62 | 1   |
| 66   | LST3000-05000    | Front Support Leg      | 1   |
| 67   | 9101-10025-DX    | Hex Bolt M10x25        | 4   |
| 68   | LST3000-06000    | 6" Caster              | 1   |
| 69   | LSP25-09001      | Aluminum Base          | 1   |
| 70   | LSP25-09002      | Filter                 | 1   |

## Parts Drawing & Parts List

| Ref# | Drawing No.       | Description                    | Qty |
|------|-------------------|--------------------------------|-----|
| 71   | LSE22-00014       | Oil Pipe                       | 1   |
| 72   | LSP25-00011-BXG   | Clamp                          | 2   |
| 73   | 9306-06000-DX     | Lock Washer Ø6                 | 6   |
| 74   | LSP25-15000-DX    | Filter Mounting Plate          | 1   |
| 75   | LSP25-00021       | Rubber Washer                  | 1   |
| 76   | LSP25-00022       | Oil Filter                     | 1   |
| 77   | LSE22-00007       | Safety Pin                     | 1   |
| 78   | LSE22-00008       | Spring                         | 1   |
| 79   | LSP25-13000       | Oil Bolt                       | 1   |
| 80   | LSH2200-03000     | Oil Tank                       | 1   |
| 81   | LSP25-00010-DX    | Oil Plug                       | 1   |
| 82   | 9101-10030-DX8.8  | Hex Bolt M10x30                | 6   |
| 83   | LSA22-00021       | Rubber 2                       | 6   |
| 84   | 9306-10000-DX     | Lock Washer Ø10                | 6   |
| 85   | LSA22-18000       | Right Fender                   | 1   |
| 86   | 9101-08065-DX8.8  | Hex Bolt M8x65                 | 4   |
| 87   | LSP25-00025       | Polyurethane Block             | 4   |
| 88   | 9302-10000-DX     | Large Flat Washer Ø10          | 4   |
| 89   | 9306-08000-DX     | Lock Washer Ø8                 | 12  |
| 90   | LSP25-10001       | Engine                         | 1   |
| 91   | 9101-05010-DX8.8Q | Hex Bolt M5x10                 | 4   |
| 92   | LSP25-10006       | Coupling Guard                 | 1   |
| 93   | LSP25-10005       | Gear Pump Stand                | 1   |
| 94   | 9101-08025-DX8.8  | Hex Bolt M8x25                 | 4   |
| 95   | LSP25-10004-DX    | Engine Bushing                 | 1   |
| 96   | /                 | 5x25 Flat Key                  | 1   |
| 97   | LSP25-10002-FH    | Engine Coupling                | 1   |
| 98   | LSP25-10003-FH    | Gear Pump Coupling             | 1   |
| 99   | /                 | Flat Key                       | 1   |
| 100  | 9121-06010-FH     | Screw M6x10                    | 1   |
| 101  | LSP25-10008-FH    | Steel Wire Snap Ring for Shaft | 1   |
| 102  | LSP2501-07001     | Gear Pump13/1.8                | 1   |
| 103  | 9101-08030-DX8.8Q | Hex Bolt M8x30                 | 4   |
| 104  | LSH22-08001       | Connector                      | 1   |