RedGum Little Aussie Log Splitter (Post-2017 model)

Illustrated Parts Listing (IPL)

RedGum Products


For more information contact your local RedGum Dealer Visit: www.RedGumProducts.com.au

Phone: 1300 039 251



Follow us on Facebook: www.facebook.com/redgumproducts

Parts Drawing & Parts List



Parts Drawing & Parts List

Ref#	Drawing No.	Description	Qty
1	HZ01001-01-100	Oil Tank	1
2	HZTY-042-000	Right and Left Protection Fender	2
3	GB/T5783-2000	Hex bolt M10×25	5
4	HZTY-070-001	Tire/Wheel	2
5	GB/T 95-2002.	Flash Washer Ø20	2
6	GB/T 6181-1986	Hex Slotted Nut M20×1.5	2
7	GB/T 91-2000	Cotter Pin d4×40	. 2
8	HZTY-070-002	Axle Cap	2
9	HZTY-051	Shock Pad Ø40×25	4
10	GB/T5287-1985	Big Flat Washer Ø8	4
11	HZTY-068	Engine	. 1
12	GB/T5782-2000	Hex Bolt M8×70	- 4
13	GB/T5782-2000	Hex Bolt M10×80	1
14	GB/T5782-2000	Hex Bolt M12×90.	. 1
15	HZTY-080	Hitch Pin	1
16	GB/T95-2002	Flat Washer Ø8	12
17	GB/T95-2002	Flat Washer Ø6	6
18	GB/T95-2002	Flat Washer Ø12	21
19	GB/T95-2002	Flat Washer Ø10	10
20	GB/T889.1-2000	Nylon Lock Nut M8	8
21	GB/T5783-2000	Hex bolt M10×20	2
22	GB/T5783-2000	Hex bolt M6×20	6
23	GB/T5783-2000	Hex bolt M8×25	5
24	GB/T5783-2000	Hex bolt M8×30	4
25	GB/T5783-2000	Hex bolt M5×10	4
26	GB/T5783-2000	Hex bolt M12×35	4
27	GB/T5783-2000	Hex bolt M10×30	4
28	GB/T 93-1987	Spring Washer Ø8	4
29	GB/T 93-1987	Spring Washer Ø10	2 ,
30	HZTY-002-000	Oil Plug	1
31	GB/T 93-1987	Spring Washer Ø6	6
32	GB/T 93-1987	Spring Washer Ø18	4
33	GB/T 93-1987	Spring Washer Ø12	10
34	GB/T70.2-2000	Screw M8×10	4
35	HZTY-003	Drain Plug	1
36	HZTY-046	Engine Spacer	1

Ref#	Drawing No.	Description	Qty
37	GB/T 1096-2003	Flat Key 5×5×25	1
38	GB/T 1096-2003	Flat Key 3×3×25	1
39	HZTY-056	Engine Connector	1.
40	HZTY-075	Gear Pump Bracket	1
41	HZTY-055	Gear Pump Connector	1
42	HZTY-066	Gear Pump	1
43	GB/T78-2000	Hex Socket Set Screws M6×10	. 1
44	HZTY-040	Pump Bracket Cover	1
45	HZTY-062	Gear Pump Joint	1-
46	HZTY-067	Clamp	2
47	HZTY-052	Bottom Hose	1
48	HZ01004-02	Joint (Hose-Tank)	1
49	HZTY-038-000	Rear Support Leg	1
50	HZTY-037-002	Spring	1
51	HZTY-037-003	Safety Pin	1
52	HZ01004-05-000	Tow Bar	1
53	HZTY-004-000	Flange	1
54	GB/T 3452.1-2005	Q Ring Ø80×2.4	.1
55	GB/T 3452.1-2005	O Ring Ø75×2.4	1
56	HZTY-005	Filter	1
57	GB/T889.1-2000	Nylon Lock Nut M12	7
58	GB/T889.1-2000	Nylon Lock Nut M10	7
59	HZTY-069	Hitch Pin Ø10	1
60	GB/T91-2000	Cotter Pin d5×40	1
61	GB/T91-2000	Cotter Pin d5×50	1
62	HZTY-065	Coupler	1
63	GB/T5782-2000	Hex bolt M12×130	2
64	HZTY-058	Hydraulic Hose (Valve-Oil Tank)	1
65	HZ01004-03	Front Support Leg Pin	1
66	HZ01004-04-000	Front Support Leg	1
67	HZTY-059	Hydraulic Hose (Pump-Valve)	1
68	GB/T 3452.1-2005	O Ring Ø16×2.4	1
69	HZTY-043	Valve Operation	1
70	HZTY-063	Bolt Connector M14×1.5	2
71	HZTY-057	Hydraulic Hose (Valve - Cylinder)	1
72	HZTY-073	Obtuse Angle Joint M27×1.5	1

Ref#	Drawing No.	Description	Qty
73	HZTY-053	Safety Chain with Hook Ø6	2
74	HZ01004-01-000	Beam	1
75	HZTY-054	R Pin Ø3×55	4
76	HZTY-039-000	Cylinder	1
77	GB/T95-2002	Flat Washer Ø18	4
78	GB/T41-2000	Hex Nut M18	. 4
79	GB/T41-2000	Hex Nut M8	1
80	GB/T 41-2000	Hex Nut M12	10
81	HZTY-039-007	Piston Rod Joint M30×2	1
82	HZTY-041-000	Wedge	1
83	HZTY-047	Wedge Platen	_ 2
84 -	HZTY-064	Joint (Valve-Hose)	1
85	GB/T 3452.1-2005	O Ring Ø22×2.4	1
86	HZTY-072	Control Valve	1
87	HZTY-0050	Wood Tray	1
88	HZTY-045	Hitch Pin	1
89	GB/T 3452.1-2005	O Ring Ø20×2.4	,2-
90	HZTY-044	Wedge Pin	1
91	HZTY-076	Screw M12×55	10
92	. HZTY-074	Straight Joint	1
93	HZTY-061	Cylinder Joint	1
94	GB/T91-2000	Cotter Pin d3.2×25	2